

PART LIST:

Parts included:

- 01: INFLATABLE SLIDE WITH BALL PIT x 1 PACK
- 02: BALLS X 20 PIECES
- 03: REPAIR PATCH X 1 PACK

WARNING!

Read this manual before assembling and using the product. Failure to follow these instructions could result in serious injury or death. They are not life saving devices. Never leave children near water unattended and be sure they are supervised by a mature and knowledgeable adult.

WARNING!

Keep away from fire! Use only under competent supervision. Never leave young children unattended. Not to be used as a flotation device. Empty and store safely when not in use. For health reasons empty water every day. Adult assembly required. To inflate: Squeeze the valve then blow air into the compartments. To deflate: Pull out the stopper then squeeze the valve direction, inflate with either a foot pump, hand pump or low pressure electric pump (Do not use high pressure compressors). Pump not included.

SAFETY CHECKLIST: READ BEFORE USING**SET UP:**

1. Before set up: Check the area where the product will be placed for sharp objects, rocks, sticks, lawn sprinklers or any other objects that can cause injury or damage to the product. Set up on a flat lawn surface, free of depressions or raised spots.
2. This product should be placed at least 305cm away on all sides from trees, walls, holes, garden equipment, pools and other objects.
3. Inspect this product for rips, tears or punctures. Do not use if damaged.
4. Open the water reservoir valve which is on the side of the slide and fill the reservoir. Close the valve securely to prevent leaking. Repeat for the other side of the water bag.
5. Inflate the slide and ball pit with AIR. Remove the valve plug from the valve and insert the appropriate attachment of your inflation device and inflate until almost firm. Close Valve plug.
6. Insert the deflation portion of the inflation/deflation device with the appropriate attachment connector. You may also gently squeeze the base of the valve to release air. You will know you have all the air out when the unit is flat and wrinkled.

USE:

1. Maximum loading: 25KG.
2. Competent adult set up and supervision is required at all times. Responsible adults should instruct children on the proper use of this product.
3. Remove all hard or sharp objects such as toys, buckles, keys, jewellery, watches, etc. from children and pockets.
4. NEVER DIVE HEAD FIRST.
5. Always slide with your feet first and never slide on your knees, stomach, head first or standing up.
6. No diving.
7. Only one child should be on the sliding surface at a time.

AFTER USE:

1. Carefully deflate, dry, roll up and store this product when not in use.
2. Do not store the product indoors or in a closed container until it is completely dry.
3. Store this product in a secure place, away from children to prevent suffocation.